

Application note

DA9212 Standard Variants Overview

AN-PM-051

Abstract

This application note describes all the register default settings of the DA9212 standard variants.

Contents

Contents	2
1 Variant table and ordering information	3
2 DA9212-AKUU2 detailed description	3
3 DA9212 standard variants comparison.....	5
4 Revision history	6

1 Variant table and ordering information

Table 1: Variant Table

Part Number	Package	Shipment Form	Pack Quantity	Comments
DA9212-AKUU2	42 WL-CSP	Tape and Reel	5000	

2 DA9212-AKUU2 detailed description

Key settings:

- Default output voltage set to 1.00V
- Maximum allowed output voltage set to 1.31V
- Bucks operate in PWM mode with phase shedding. An automatic transition to low power mode on both Buck A and Buck B must be configured by register write
- GPIO0, GPIO1, GPI4 configuration prepared for input mode
- Buck A enabled by GPIO0 and Buck B enabled by GPI1
- GPIO2 configuration is output push-pull as Buck A power good signal
- GPIO3 configuration is output push-pull as Buck B power good signal
- nIRQ pin configured as open drain
- 2-wire control interface, standard speed

Table 2: Register Settings DA9212-AKUU2 variant

Register Address	Function	Default Value	Description
0x054	MASK_A	0x5F	nIRQ interrupt at GPIO0 to GPI4 and UVLO_IO caused nIRQ are masked
0x055	MASK_B	0x3F	PWRGOOD Buck A & Buck B, TEMP_WARN, TEMP_CRIT, OV_CURR Buck A & OV_CURR Buck B caused event are masked
0x056	CONTROL_A	0x53	GPIO denounce time = 10ms DVC slew rate A = 10mV/us DVC slew rate B = 10mV/us V_LOCK = 0: Allows host writes into registers 0xD0 to 0x14F
0x058	GPIO0-1	0x44	GPIO0: input, active high, denouncing off GPIO1: input, active high, denouncing off
0x059	GPIO2-3	0x77	GPIO2: output, push-pull, active high, sets output passive level GPIO3: output, push-pull, active high, sets output passive level
0x05A	GPI4	0x04	GPI4: input, active high, denouncing off
0x05D	BUCKA_CONT	0x02	Buck A enabled by GPIO0 Enable pull down resistor of Buck A when the buck is disabled Buck output voltage is selected from VBUCKA_A
0x05E	BUCKB_CONT	0x04	Buck B enabled by GPI1 Enable pull down resistor of Buck B when the buck is disabled Buck output voltage is selected from VBUCKB_A
0x0D0	BUCK_ILIM	0x5C	Buck A current limit per phase BUCKA_ILIM=4400mA Buck B current limit per phase BUCKA_ILIM=3000mA (peak current on the inductor)

Register Address	Function	Default Value	Description
0x0D1	BUCKA_CONF	0x92	Buck A always operates in PWM mode Start up control: 20mV/us Down control: 20mV/us
0x0D2	BUCKB_CONF	0x92	Buck A always operates in PWM mode Start up control: 20mV/us Down control: 20mV/us
0x0D3	VBUCK_CONF	0x1F	Buck A in PWM mode, 2 phases are selected and current dependant phase shedding in PWM is enabled Buck B in PWM mode, 2 phases are selected and current dependant phase shedding in PWM is enabled
0x0D5	VBUCKA_MAX	0x65	Buck A max output voltage VBUCKA_MAX = 1.31V
0x0D6	VBUCKB_MAX	0x65	Buck B max output voltage VBUCKB_MAX = 1.31V
0x0D7	VBUCKA_A	0x46	Output voltage VBUCKA_A = 1.00V
0x0D8	VBUCKA_B	0x46	Output voltage VBUCKA_B = 1.00V
0x0D9	VBUCKB_A	0x46	Output voltage VBUCKB_A = 1.00V
0x0DA	VBUCKB_B	0x46	Output voltage VBUCKB_B = 1.00V
0x105	INTERFACE	0xD9	2-wire control interface slave address = 0xD0
0x106	INTERFACE2	0x80	Power management interface is 2-wire, standard speed
0x143	CONFIG_A	0x12	Enabled automatic reset of 2-WIRE interface in case of clock stays low for >35ms nIRQ output port is open drain, active low GPIs are supplied from VDDCORE
0x144	CONFIG_B	0x60	Buck A Power good signal masked during DVC transitions (keep previous status) Buck A Power good signal masked during DVC transitions (keep previous status)
0x145	CONFIG_C	0x00	GPI0, GPI1 and GPI4 : GPI pull down resistors disabled GPIO2 and GPIO3 GPI pull down resistor disabled, GPO pull up resistor disabled
0x146	CONFIG_D	0x90	Select GPIO2 is Buck A PG (POWER GOOD) signal Select GPIO3 is Buck B PG (POWER GOOD) signal
0x147	CONFIG_E	0xC0	DA9212 is stand-alone device (not together with DA9063) No tune of oscillator frequency
0x148	CONFIG_F	0xD0	0xD0 write address of PM 2-WIRE interface (page 0 and 1)

3 DA9212 standard variants comparison

Table 3: Standard variants overview

Register Address	Function	Standard Variant DA9212-					
		AKUU2					
0x054	MASK_A	0x5F					
0x055	MASK_B	0x3F					
0x056	CONTROL_A	0x53					
0x058	GPI0-1	0x44					
0x059	GPI02-3	0x77					
0x05A	GPI4	0x04					
0x05D	BUCKA_CONT	0x02					
0x05E	BUCKB_CONT	0x04					
0x0D0	BUCK_ILIM	0x5C					
0x0D1	BUCKA_CONF	0x92					
0x0D2	BUCKB_CONF	0x92					
0x0D3	BUCK_CONF	0x1F					
0x0D5	VBUCKA_MAX	0x65					
0x0D6	VBUCKB_MAX	0x65					
0x0D7	VBUCKA_A	0x46					
0x0D8	VBUCKA_B	0x46					
0x0D9	VBUCKB_A	0x46					
0x0DA	VBUCKB_B	0x46					
0x105	INTERFACE	0xD9					
0x106	INTERFACE2	0x80					
0x143	CONFIG_A	0x12					
0x144	CONFIG_B	0x60					
0x145	CONFIG_C	0x00					
0x146	CONFIG_D	0x90					
0x147	CONFIG_E	0xC0					
0x148	CONFIG_F	0xD0					

4 Revision history

Revision	Date	Description
1.0	17-Dec-2014	Initial version

Disclaimer

Information in this document is believed to be accurate and reliable. However, Dialog Semiconductor does not give any representations or warranties, expressed or implied, as to the accuracy or completeness of such information. Dialog Semiconductor furthermore takes no responsibility whatsoever for the content in this document if provided by any information source outside of Dialog Semiconductor.

Dialog Semiconductor reserves the right to change without notice the information published in this document, including without limitation the specification and the design of the related semiconductor products, software and applications.

Applications, software, and semiconductor products described in this document are for illustrative purposes only. Dialog Semiconductor makes no representation or warranty that such applications, software and semiconductor products will be suitable for the specified use without further testing or modification. Unless otherwise agreed in writing, such testing or modification is the sole responsibility of the customer and Dialog Semiconductor excludes all liability in this respect.

Customer notes that nothing in this document may be construed as a license for customer to use the Dialog Semiconductor products, software and applications referred to in this document. Such license must be separately sought by customer with Dialog Semiconductor.

All use of Dialog Semiconductor products, software and applications referred to in this document are subject to Dialog Semiconductor's [Standard Terms and Conditions of Sale](#), unless otherwise stated.

© Dialog Semiconductor GmbH. All rights reserved.

RoHS Compliance

Dialog Semiconductor complies to European Directive 2001/95/EC and from 2 January 2013 onwards to European Directive 2011/65/EU concerning Restriction of Hazardous Substances (RoHS/RoHS2).

Dialog Semiconductor's statement on RoHS can be found on the customer portal <https://support.diasemi.com/>. RoHS certificates from our suppliers are available on request.

Contacting Dialog Semiconductor

Germany Headquarters

Dialog Semiconductor GmbH
Phone: +49 7021 805-0

United Kingdom

Dialog Semiconductor (UK) Ltd
Phone: +44 1793 757700

The Netherlands

Dialog Semiconductor B. V.
Phone: +31 73 640 8822

Email:

enquiry@diasemi.com

North America

Dialog Semiconductor Inc.
Phone: +1 408 845 8500

Japan

Dialog Semiconductor K. K.
Phone: +81 3 5425 4567

Taiwan

Dialog Semiconductor Taiwan
Phone: +886 281 786 222

Web site:

www.dialog-semiconductor.com

Singapore

Dialog Semiconductor Singapore
Phone: +65 64 849929

China

Dialog Semiconductor China
Phone: +86 21 5178 2561

Korea

Dialog Semiconductor Korea
Phone: +82 2 3469 8291