

# User Manual

## Provisioning Mobile-App for Android

### UM-WI-025

#### **Abstract**

*This document describes the use of Dialog's Wi-Fi provisioning mobile-App for Android*

---

---

## Contents

<b>Abstract</b> .....	<b>1</b>
<b>Contents</b> .....	<b>2</b>
<b>Figures</b> .....	<b>2</b>
<b>Tables</b> .....	<b>2</b>
<b>1 Terms and Definitions</b> .....	<b>3</b>
<b>2 Overview</b> .....	<b>3</b>
<b>3 System Requirement</b> .....	<b>3</b>
<b>4 Sequence Diagram for Wi-Fi Provisioning</b> .....	<b>4</b>
<b>5 How to Test Provisioning</b> .....	<b>5</b>
5.1 Switch the DA16200 to AP Mode.....	5
5.2 Start the Dialog Provisioning Tool.....	5
5.3 Set the data for provisioning. ....	6
<b>Revision History</b> .....	<b>8</b>

## Figures

Figure 1: System Diagram for Wi-Fi Provisioning .....	4
Figure 2: Switch the DA16200 to AP Mode.....	5
Figure 3: Start the Dialog Provisioning Tool for Android and find DA16200 .....	5
Figure 4: Set the data for provisioning .....	7

## Tables

## Provisioning Mobile-App for Android

### 1 Terms and Definitions

TCP	Transmission Control Protocol
TLS	Transport Layer Security
UDP	User Datagram Protocol
AP	Access Point

### 2 Overview

This document describes how to configure the DA16200 Wi-Fi profile information using by Dialog's Wi-Fi provisioning mobile-app for Android.

### 3 System Requirement

- Android OS Version: 5.0(Lollipop)+
- IDE: Android Studio 4.0
- Compile SDK Version: 30
- Language: Java
- Gradle Version: 4.0.0

Provisioning Mobile-App for Android

4 Sequence Diagram for Wi-Fi Provisioning




Figure 1: System Diagram for Wi-Fi Provisioning

Provisioning Mobile-App for Android

5 How to Test Provisioning

5.1 Switch the DA16200 to AP Mode

Use the Factory Reset or Switch button (depends on device option) to switch the DA16200 (FC9000) to AP Mode.




Figure 2: Switch the DA16200 to AP Mode

5.2 Start the Dialog Provisioning Tool







Figure 3: Start the Dialog Provisioning Tool for Android and find DA16200

Provisioning Mobile-App for Android

5.3 Set the data for provisioning.



3. You can choose TLS provisioning. If you choose TLS provisioning, your device will be connected to the Dialog AP through a secure connection.



5. In the Wi-Fi Scan results, select a Wi-Fi AP for provisioning.

Provisioning Mobile-App for Android




Figure 4: Set the data for provisioning

---

**Provisioning Mobile-App for Android****Revision History**

Revision	Date	Description
1.0	15-May-2020	- Preliminary DRAFT Release.
1.1	22-July-2020	- Add a TLS provisioning function
1.2	04-Sep-2020	- Correction: "Find Wi-Fi for Provisioning" → "Select the Wi-Fi router you want the target device to join." - Correction: "Start Provisioning" → "Go!" - Remove country code - Add provisionig complete notice.
1.3	18-Sep-2020	- Change UI text - Add provisioning complete dialog - Remove SNTP, DPM setup



## Provisioning Mobile-App for Android

### Status Definitions

Status	Definition
DRAFT	The content of this document is under review and subject to formal approval, which may result in modifications or additions.
APPROVED or unmarked	The content of this document has been approved for publication.

### Disclaimer

Unless otherwise agreed in writing, the Dialog Semiconductor products (and any associated software) referred to in this document are not designed, authorized or warranted to be suitable for use in life support, life-critical or safety-critical systems or equipment, nor in applications where failure or malfunction of a Dialog Semiconductor product (or associated software) can reasonably be expected to result in personal injury, death or severe property or environmental damage. Dialog Semiconductor and its suppliers accept no liability for inclusion and/or use of Dialog Semiconductor products (and any associated software) in such equipment or applications and therefore such inclusion and/or use is at the customer's own risk.

Information in this document is believed to be accurate and reliable. However, Dialog Semiconductor does not give any representations or warranties, express or implied, as to the accuracy or completeness of such information. Dialog Semiconductor furthermore takes no responsibility whatsoever for the content in this document if provided by any information source outside of Dialog Semiconductor.

Dialog Semiconductor reserves the right to change without notice the information published in this document, including, without limitation, the specification and the design of the related semiconductor products, software and applications. Notwithstanding the foregoing, for any automotive grade version of the device, Dialog Semiconductor reserves the right to change the information published in this document, including, without limitation, the specification and the design of the related semiconductor products, software and applications, in accordance with its standard automotive change notification process.

Applications, software, and semiconductor products described in this document are for illustrative purposes only. Dialog Semiconductor makes no representation or warranty that such applications, software and semiconductor products will be suitable for the specified use without further testing or modification. Unless otherwise agreed in writing, such testing or modification is the sole responsibility of the customer and Dialog Semiconductor excludes all liability in this respect.

Nothing in this document may be construed as a license for customer to use the Dialog Semiconductor products, software and applications referred to in this document. Such license must be separately sought by customer with Dialog Semiconductor.

All use of Dialog Semiconductor products, software and applications referred to in this document is subject to Dialog Semiconductor's [Standard Terms and Conditions of Sale](http://www.dialog-semiconductor.com), available on the company website ([www.dialog-semiconductor.com](http://www.dialog-semiconductor.com)) unless otherwise stated.

Dialog, Dialog Semiconductor and the Dialog logo are trademarks of Dialog Semiconductor Plc or its subsidiaries. All other product or service names and marks are the property of their respective owners.

© 2020 Dialog Semiconductor. All rights reserved.

### RoHS Compliance

Dialog Semiconductor's suppliers certify that its products are in compliance with the requirements of Directive 2011/65/EU of the European Parliament on the restriction of the use of certain hazardous substances in electrical and electronic equipment. RoHS certificates from our suppliers are available on request.

## Contacting Dialog Semiconductor

#### United Kingdom (Headquarters)

*Dialog Semiconductor (UK) LTD*  
Phone: +44 1793 757700

#### Germany

*Dialog Semiconductor GmbH*  
Phone: +49 7021 805-0

#### The Netherlands

*Dialog Semiconductor B.V.*  
Phone: +31 73 640 8822

#### Email:

[enquiry@diasemi.com](mailto:enquiry@diasemi.com)

#### North America

*Dialog Semiconductor Inc.*  
Phone: +1 408 845 8500

#### Japan

*Dialog Semiconductor K. K.*  
Phone: +81 3 5769 5100

#### Taiwan

*Dialog Semiconductor Taiwan*  
Phone: +886 281 786 222

#### Web site:

[www.dialog-semiconductor.com](http://www.dialog-semiconductor.com)

#### Hong Kong

*Dialog Semiconductor Hong Kong*  
Phone: +852 2607 4271

#### Korea

*Dialog Semiconductor Korea*  
Phone: +82 2 3469 8200

#### China (Shenzhen)

*Dialog Semiconductor China*  
Phone: +86 755 2981 3669

#### China (Shanghai)

*Dialog Semiconductor China*  
Phone: +86 21 5424 9058